





Easy to move the Joy Stick, just turn ① and pull it of ②.

An extra part like ② follows for easy fitting of the Joy Stick control box near operator.

Speed adjustment of sideways movement's ③ in proportion to situation and experience.